




28-TN5PD-Pull Start  
 28-TN5PD-Starter  
 28-TN5PD-Start Box



No	Part No	Description	Qty.
1	E39-BU02100	Cooling Head Screw	4
2	DC-E028001-09	Cooling Head	1
3	E15-ST02800	Head Shim 0.1mm	5
4	E01-ST02850	Set Piston/Sleeve 5PT	1
5	E38-BU02101	Piston Pin Clips	4
6	TU-E028003	Piston Pin 28	1
7	E02-BU02103R	Connecting Rod 21	1
8	E03-ST02850R	28 Complete Set Piston/Sleeve 5PT/Rod	1
9	E05-BU02117	Carburetor	1
10	E33-BU02103	Carburetor Upper O-Ring	5
11	E32-BU02100	Carburetor Lower O-Ring	5
12	TU-E021022	Flywheel Collet	1
13	E11-BU02104	Carburetor Retainer(RTR)	1
14	BR-U00R607	Front Ball Bearing	1
15	E21-ST02802	RTR Crankcase 28 Set	1
16	BR-U0AY14A	Rear Ball Bearing	1
17	TU-E028084	Crankshaft 28 (RTR)	1
18	E18-BU02101	One Way Bearing Set	1
19	E31-BU02100	Backplate Cover 21 O-Ring	5
20	E43-BU02101	Pull Start Backplate Cover With O-Ring	1
21	E40-BU02100	Backplate Cover Scerw	4
22	TU-E021114	Thrust Shaft	1
23	E71-BU02100	One Way Bearing-Back Cover Set	1
24	E14-BU02100	Pull Starter	1
25	E42-BU02100	Pull Start Backplate Cover M2.6*8 Screw	4
26	E41-BU02100	Rubber Adaptor for Manifolds	2
27	DC-E028009	Backplate Cover 21	1
28	E13-ST02801	Backplate Cover 28 With O-Ring(RTR)	1
29	E17-SEUTD01	Starter Backplate Set	1
30	E42-BU02101	Starter Backplate Cover Screw	4
31	E10-BU02101	Full Speed Needle Set	1
32	E50-BU02100	High Speed Needle With O-Ring	1
33	TU-E021012	Main Needle Socket	1
34	E07-BU02100	Fuel Supply Nipple Set	1
35	E28-BU02100	Dust Protection Bellows	2
36	E36-BU02100	Carburetor Ball Linkage With Screw	1
37	E46-BU02103	Low Speed Needle & O -Ring	1
38	E68-BU02100	Idle Adj Screw With O-Ring	1
39	E34-BU02100	Needle O-Ring	8
40	E29-BU02102	O-Ring Kit for Carburetor	1

For more spare parts, please visit  
[www.alpha-rc.com](http://www.alpha-rc.com)  
 We reserve the right to make changes without  
 notice.03.07.2022